

## Terry Classic Coax Wiring – submitted by Robert A. Bimbi

One splitter is located behind the iRV unit. It is also accessible by removing the face plate. The second splitter is in the wall behind the faceplate in the bedroom.

Please note that one coax box in the front room has an electronic switch or signal booster. It must be ON for antenna and OFF for cable.

The dedicated loop from the second input outside – to the Bedroom – then to the front room really does not make sense as wired. I changed the terminals on the splitter in the bedroom so the outside input goes to the INPUT of the splitter. Then both outputs go to the TV's.

This dedicated loop as wired (with a little modification) would allow for a Satellite dish on a tripod to the input, or a roof mount satellite dish. The wiring between the TV's in the loop is all over head in the ceiling joists.

