
## **Part Names**



- \*1: See pages 12, 17, and 18 for external equipment connection.
- \*2: See page 19 and 28 for button operations.
- \*3: See page 10 for connecting the AC cord.

#### NOTE

• The illustrations in this operation manual are for explanation purposes and may vary slightly from the actual operations.


# Connecting to External Equipment

You can connect many types of external equipment to your TV like a Blu-ray disc player, HD-DVD player, DVD player, VCR, HDMI equipment, game console or camcorder. To view external source images, select the input source from **INPUT** on the remote control unit or **INPUT** on the TV. (See page 21.)

### CAUTION

- To protect equipment, always turn off the TV before connecting any external equipment.
- Please read the relevant operation manual (Blu-ray disc player, etc.) carefully before making connections.

Connecting a Blu-ray disc player, HD-DVD player, DVD player, VCR, game console or camcorder.



### NOTE

- Digital Audio Output cannot be used for all IHDMI Inputs.
- \*1 When using an HDMI-DVI conversion cable, input the audio signal to AUDIO terminal of PC IN.
  - To enjoy the 1080p display capability, connect your Blu-ray disc player, HD-DVD player or other external equipment using an HDMI-certified cable and set the equipment to 1080p output.