



RECOMMENDED REPAIR METHOD FOR ALPHA SYSTEMS ROOF SEALANT

During routine cleaning (3-4 times a year), all caulk and sealants should be inspected for voids or cracking. If the caulk is cracking, pull up any loose caulk. Do not use any tools, such as a putty knife, that could puncture the rubber roof membrane. If you cannot pull the caulk off by hand, it is still adhered to the roof and should be left alone.

Clean the areas to be re-sealed using regular soap and water. The area must be dry before continuing.

Apply a generous amount of **Alpha Systems 1010 Sealant** over the top of any existing caulk in the area being re-sealed.

To order products now, call 800-462-4698. Please allow 3-5 business days before product ships from our facility. Shipping charges will be added to your order.

Solvents should not be used during cleaning. Solvents can damage existing caulk and may weaken plastic parts that are present on the roof.