



DESIGNED TO MOVE [YOU][®]

AWM965 Quick Reference Guide

Basic Operation



VOL: Rotate *clockwise* to INCREASE or *counter-clockwise* to DECREASE volume output.

AUDIO: Each press of the control will bring up the following AUDIO ADJUSTMENT options: BASS, TREBLE, BALANCE (left to right), & FADE (front to back).

ADJUST LCD BRIGHTNESS: Press and hold to access the user menu. Press to navigate to "LIGHT". Rotate to adjust the standby mode LCD brightness from "LIGHT 1" (least bright) to "LIGHT 3" (brightest).



T/F CLOCK: Press to display CLOCK.

SPEAKER OUTPUT: Press any speaker button (SPEAKER A, SPEAKER B, or SPEAKER C) to control corresponding speaker output from the stereo.

AUX AV IN: Insert 3.5mm audio/video jack.

MUTE: Press to MUTE audio.

POWER: Push to turn ON or OFF.

AM/FM Tuner Controls



VOL: Rotate *clockwise* to INCREASE or *counter-clockwise* to DECREASE volume output.

AS/PS: Press to SCAN through currently stored presets. Press & hold to STORE strongest broadcast stations in your area.



TUNE/TRACK: Rotate *counter-clockwise* to TUNE DOWN in frequency in AM or FM Mode. Rotate *clockwise* to TUNE UP in frequency AM or FM Mode. Rotate and hold to scan to next strongest station.

AM/FM: Press to directly access TUNER MODE. Press to select between two AM BANDS (AM1 & AM2) & three FM BANDS (FM1, FM2, & FM3).

MUTE: Press to MUTE audio.

STATION STORE BUTTONS: Press & hold to store current channel playing. Momentarily press to recall stored channel. NOTE: you can store up to 30 channels (6 channels per band FM1, FM2, FM3, AM1, AM2).




VOL: Rotate clockwise to INCREASE or counter-clockwise to DECREASE volume output.

MUTE: Press to MUTE audio.

MENU: Press to access main DVD MENU.

DVD/USB: Press to select DVD/USB mode.



TUNE/TRACK: Rotate clockwise to tune to NEXT TRACK or CHAPTER/TITLE. Rotate counter-clockwise to tune to PREVIOUS TRACK or CHAPTER/TITLE. In CD MODE, rotate and hold to FAST FORWARD or REWIND current play. In DVD MODE, rotate and hold to enter FAST FORWARD/RW. Momentarily turn to step through x2, x4, x8, x20. Press PLAY to resume.

EJECT: Press to EJECT CD or DVD.

PLAY/PAUSE: Press to PLAY or PAUSE current audio or video.

INTRO SCAN: Press to play each track for 10 seconds in sequential order. Press again to SELECT desired play.

RPT: Press to REPEAT current playing track. Press to release function.

RDM: Press to play each track in RANDOM order. Press again for NORMAL play.

STOP: Press to SUSPEND disc play. Press PLAY/PAUSE to RESUME disc play.

LANG: Press to select AUDIO LANGUAGE when in DVD MODE.

USB: Plug in USB device

MENU: Press to access main DVD MENU.

DIRECTIONAL ARROWS: Press to move cursor to desired MENU ITEM. Press ENTER to select desired MENU ITEM.

T/F: Press to display CLOCK.
STOP: Press once SUSPEND disc play. Press PLAY/PAUSE to RESUME disc play. Press twice to completely stop disc play.

LANG: Press to select AUDIO LANGUAGE.

SUBTITLES: Press to select CLOSED CAPTIONING. Continue to press to select AUDIO LANGUAGE.

SETUP: Press to enter SETUP MENU.



MUTE: Press to MUTE audio.

EJECT: Press to EJECT DVD.

CHAPTER SKIP: Press to skip to NEXT or PREVIOUS chapter.

ENTER: Press to select menu option.
FAST FORWARD/REWIND: Press to FAST FORWARD or REWIND current play. Continue to press to enhance the speed. Press PLAY/PAUSE to resume current play.

PLAY/PAUSE: Press to PLAY or PAUSE current audio.

TITLE: Press to enter TITLE MENU. Use the DIRECTIONAL ARROWS to choose menu item. Press ENTER to select.

RPT: Press to REPEAT current CHAPTER. Press again to release function.

SOURCE: Press to select for PLAYBACK.

ZOOM: Press to ZOOM in on current picture. Press repeatedly to change MAGNIFICATION LEVEL of current picture.

ANGLE: Press to select different visual angle if stored on DVD.

GOTO: Press to view CHAPTER, TRACK, & TIME. Press again to clear.

DISPLAY: Press to DISPLAY current playback information on the screen.



TUNE/TRACK: Rotate UP or DOWN to adjust HOUR and MINUTES once in CLOCK MODE or ALARM SETTING MODE.

T/F CLOCK: Press to display current time. Press & hold to enter CLOCK SETTING MODE. Rotate TUN/TRK encoder knob to adjust the HOUR. Press T/F again and rotate TUN/TRK encoder knob to adjust the MINUTES. Once desired time has been selected, the time will set after 5 seconds.

ALARM: Press ALARM SET to cycle through SLEEP TIMER MODE. Press and hold to enter ALARM SETTING MODE. Rotate TUN/TRK encoder knob to adjust the HOUR. Press ALARM SET again and rotate TUN/TRK encoder knob to adjust the MINUTES. Once desired time has been selected, press ALARM ON/OFF to turn ALARM MODE ON or OFF.